Nimbus Digital Combination Lock Range

FUNCTION	MODE PUBLIC	MODE PRIVATE	KEY SEQUENCE			NOTES
MASTER CODE FUNCTIONS - FOR STEPS 1-3 PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)						
			STEP 1	STEP 2	STEP 3	
CHANGE **MASTER** CODE	✓	✓	[logo] [Old Master Code]	01	[New Master Code] [New Master Code]	MASTER CODE IS **EIGHT DIGITS**
CHANGE USER CODE		✓	[logo] [Master Code]	02	[New User Code]	USER CODE IS **FOUR DIGITS**
DELETE USER CODE	✓		[Master Code]			OPENS LOCK AND DELETES USER CODE
SET / CHANGE SUB-MASTER CODE	✓	✓	[logo] [Master Code]	03	[New Sub-Master Code]	SUB-MASTER CODE IS **SIX DIGITS**
DELETE SUB-MASTER CODE	✓	✓	[logo] [Master Code]	07		DELETES SUB-MASTER CODE
OPEN LOCK	✓	✓	[Master Code]			DELETES USER CODE IN PUBLIC MODE
CLOSE LOCK		AUTO				RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
SET **PUBLIC** MODE (**FOUR** DIGIT CODES)		✓	[logo] [Master Code]	08		DELETES ALL EXISTING USER CODES
SET **PRIVATE** MODE (**FOUR** DIGIT CODES)	✓		[logo] [Master Code]	09	[New User Code]	DELETES ALL EXISTING USER CODES
SET TECHNICIAN MODE	✓		[logo] [Master Code]	10	[New Technician Code]	TECHNICIAN CODE IS **SIX DIGITS**
REMOVE TECHNICIAN MODE	✓		[logo] [Master Code]	11		DELETES TECHNICIAN CODE
SET AUDIBLE BUTTONS ON	✓	✓	[logo] [Master Code]	12		UNIT WILL BEEP ON EACH BUTTON PRESS
SET AUDIBLE BUTTONS OFF	✓	✓	[logo] [Master Code]	13		UNIT WILL OPERATE SILENTLY
SET ALARM MODE ON & SET TIME		✓	[logo] [Master Code]	14	[Time Code]	SWITCHED VERSION ONLY. SEE NOTES ON TIMERS BELOW
SET ALARM MODE OFF		✓	[logo] [Master Code]	15		SWITCHED VERSION ONLY
SET AUTO-TIMED UNLOCK ON & SET TIME	✓		[logo] [Master Code]	16	[Time Code]	SEE NOTES ON TIMERS BELOW
SET AUTO-TIMED UNLOCK OFF	✓		[logo] [Master Code]	17		UNIT WILL NOT OPEN AUTOMATICALLY
SET COIN LOCK MODE ON	✓		[logo] [Master Code]	18		SWITCHED VERSION ONLY
SET COIN LOCK MODE OFF	✓		[logo] [Master Code]	19		SWITCHED VERSION ONLY
SET REMOTE ALLOCATION MODE	✓	✓	[logo] [Master Code]	20		CAN ONLY BE USED WITH ON-LINE SOFTWARE
SET LOCK OUT MODE	✓	✓	[logo] [Master Code]	24		IF USER GETS CODE WRONG 3 TIMES - 10 SECONDS TIME OUT
REMOVE LOCK OUT MODE	✓	✓	[logo] [Master Code]	25		REMOVAL OF LOCK OUT MODE
SUB-MASTER CODE FUNCTIONS - PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)						
CHANGE USER CODE		✓	[logo] [Sub-Master Code]	02	[New User Code]	USER CODE IS FOUR OR **SIX DIGITS** (FOUR DEFAULT)
CHANGE SUB MASTER CODE	✓	✓	[logo] [Sub-Master Code]	03	[New Sub-Master Code]	SUB-MASTER CODE IS **SIX DIGITS**
DELETE USER CODE	✓		[Sub-Master Code]			OPENS LOCK AND DELETES USER CODE
OPEN LOCK	✓	✓	[Sub-Master Code]			DELETES USER CODE IN PUBLIC MODE
CLOSE LOCK		AUTO				RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
USER CODE FUNCTIONS - PLEASE ENTER THE RELEVANT NUMBERS IN THE SEQUENCE SHOWN BELOW (EG. STEP1STEP2STEP3)						
CHANGE USER CODE		✓	[logo] [Old User Code]	02	[New User Code] [New User Code]	USER CODE IS **FOUR DIGITS**
OPEN LOCK	✓	✓	[User Code]			
CLOSE LOCK	✓		[User Code] [User Code]			ENTER NEW USER CODE TWICE
CLOSE LOCK						RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS

Nimbus
digital combination locks

Nimbus Digital Combination Lock Range

FUNCTION	MODE PUBLIC	MODE PRIVATE	KEY SEQUENCE			NOTES
TECHNICIAN CODE FUNCTIONS						
OPEN LOCK	✓		[Technician Code]			DOES NOT DELETE USER CODE
CLOSE LOCK	AUTO					RE-LOCKS AUTOMATICALLY AFTER 4 SECONDS
FUNCTIONS AVAILABLE TO ALL CODES						
BATTERY CHECK	✓	✓	[logo] [logo]			REPLACE BATTERIES IF RED LIGHT SHOWS

NOTES	TIMER FUNCTIONS		TIME CODE EXAMPLES	BATTERY CONDITION INDICATOR
ALL ACCEPTABLE BUTTON PRESSES ARE SIGNIFIED BY A GREEN LIGHT.	TIME CODE	**001**	1 MIN	GREEN LIGHTS - EXCELLENT
	TIME CODE	**010**	10 MINS	ORANGE LIGHTS - GOOD
INCOMPLETE FUNCTIONS "TIME-OUT" AFTER 4 SECONDS.	TIME CODE	**030**	1/2 HR	RED LIGHTS - LOW
	TIME CODE	**060**	1 HR	FLASHING RED LIGHTS - VERY LOW
ERRORS AND "TIME-OUTS" ARE SIGNIFIED BY FLASHING RED LIGHT.	TIME CODE	**480**	8 HRS	**RED LIGHT – CHANGE BATTERIES AS SOON AS POSSIBLE**
	TIME CODE	**720**	12 HRS	
FOLLOWING AN ERROR OR "TIME-OUT", UNIT REVERTS TO PREVIOUS SETTINGS.	TIME CODE	**999**	16 HRS 39 MINS (MAXIMUM)	**FLASHING RED LIGHT PRIOR TO LOCK OR UNLOCK INDICATES LOW BATTERY VOLTAGE CHANGE BATTERIES AS SOON AS POSSIBLE**
TIME CODES ARE 3-DIGIT CODES CORRESPONDING TO THE NUMBER OF MINUTES.	**ALL TIMES ARE APPROXIMATE +/- 10%**			

MASTER CODE (8 digits)	SUB MASTER CODE (6 digits) (No Default)	USER CODE (4 DIGITS)
☐☐☐☐☐☐☐☐	☐☐☐☐☐☐	☐☐☐☐

ENSURE THAT YOU CHANGE THE DEFAULT MASTER CODE TO YOUR OWN MASTER CODE AND KEEP A SAFE RECORD - IT IS NOT POSSIBLE TO PROGRAM THE LOCK WITHOUT IT

LOWE & FLETCHER LTD

Moorcroft Drive, Wednesbury, West Midlands, WS10 7DE, UK
Tel: +44 (0) 121 505 0400 Fax: +44 (0) 121 505 0420
Email: sales@lowe-and-fletcher.co.uk
www.lowe-and-fletcher.co.uk

EURO-LOCKS SA NV

Rue de la Fontaine 8, 6600 Bastogne, Belgium
Tel: +32 61 212 261 Fax: +32 61 212 265
Email: sales@euro-locks.be
www.euro-locks.be

EURO-LOCKS GMBH

Am Bruchwald 22, 66280 Sulzbach/Neuweiler, Germany
Tel: +49 (0) 6897 9072 0 Fax: +49 (0) 6897 9072 99
Email: vertrieb@euro-locks.de
www.euro-locks.de

LOWE & FLETCHER, INC.

650 Airport Place, Norton Shores, MI-49441, Michigan, USA
Tel: +1 (616) 994 0490 Fax: +1 (616) 994 0480
Email: sales@loweandfletcherinc.com
www.loweandfletcherinc.com

EURO-LOCKS SA

1 Rue du Stade, 57730 Folschviller, France
Tel: +33 (0) 3 87 92 61 11 Fax: +33 (0) 3 87 92 42 04
Email: euro-locks@euro-locks.fr
www.euro-locks.fr

EURO-LOCKS SP. Z O.O.

ul. Pawła 29, 41-708 Ruda Śląska, Poland
Tel: +48 (32) 344-78-70, -82, -84 Fax:+48 (32) 344-78-74
Email: sekretariat@euro-locks.pl
www.euro-locks.pl

L&F A Lowe & Fletcher Group Company

9226581 – Nimbus 39960 Operating and Programming Instructions 082020 - online version