





Stool ALTUS

Disassembly & spare parts



PARTS DIAGRAM AND MATERIALS

No.	Description	Material
1	Seat	Wood
2	Frame	Metal
3	Screw	Metal



REPAIR

Carefully remove the broken part and install the new one in place using appropriate tools and fittings according to the assembly and disassembly instructions. Contact Aj Products for spare parts.

RECYCLING

To disassemble the furniture for proper recycling, start by removing all screws and fasteners. Then, separate the materials, such as wood, metal, and fabric, and take them to the appropriate recycling facility.



REPARATION

Ta bort den trasiga delen och montera den nya på plats med lämpliga verktyg och beslag enligt monterings- och demonteringsanvisningarna.

Kontakta Aj Produkter för eventuella reservdelar.

ÅTERVINNING

För att demontera möbelen för återvinning, börja med att ta bort alla skruvar och fästordningar. Separera sedan materialerna, såsom trä, metall och tyg, och lämna dem på respektive återvinningsanläggning.

